

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2043 Robe

Recommendations on fabric: well soft, soft natural/mixed knit fabric of medium stretchiness.

You will also need: zipper, knit fusible interfacing.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Main fabric:

1. Center back - cut 1 on fold
2. Side back — cut 2
3. Center front - cut 2
4. Side front – cut 2
5. Sleeve — cut 2
6. Collar – cut 2
7. Center front facing - cut 2
8. Back neck facing – cut 1
9. Pocket – cut 4

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing - cut 1
3. Collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back. Serge and press towards center.
3. Pin pockets together, right sides together and sew upper edge. Clip seam allowances, turn right side out and press pocket opening. Pin pocket at front side and baste together alongside edge and princess seam edge.
4. Sew side fronts to front. Serge and press towards center.
5. Sew shoulder and side seams, press seams towards back and serge.
6. Pin collars together right sides together and sew along outer edge. Trim seam allowances, turn the collar right side out and press. Sew collar into neckline.
7. Sew shoulder seams center front facings and facings. Press seam apart. Serge outer edge. Place center front facing onto front right sides together and sew along the center front edge, inserting zipper, at the same time sewing neckline. Trim away corners, along neckline clip. Fold center front facings onto wrong side. Slip stitch facing to shoulder seams. Sew a decorative stitch along center front edge at 0.5 cm from zipper teeth.
8. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes. Serge.
9. Serge lower edge of robe and lower edge of sleeve, press onto wrong side and topstitch.

Congratulations, your robe is ready! :)