

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2156 Jacket - bomber

Recommendations on fabric: whipcord, medium to high stretch-knit fabric.

You will also need: fusible interfacing, lining, separable zipper.

CUTTING:



The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Upper sleeve– cut 2
4. Lower sleeve - cut 2
5. Front facing - cut 2
6. Back neck facing - cut 1

The pattern pieces are marked with terns for fabric pattern alignment!

Lining:

1. Back - cut 1 on fold (A)
2. Front - cut 2 (C)
3. Upper sleeve– cut 2

4. Lower sleeve - cut 2

Fusible interfacing:

1. Front facing - cut 2
2. Back neck facing - cut 1
3. Cuff - cut 2

Knit fabric:

1. Collar - cut 1
2. Waistband - cut 1

ATTENTION: Lining is cut using main fabric patterns excluding the width of front facing. Add a pleat on lining.

INSTRUCTIONS:

1. Apply fusible interfacing to listed pieces.
2. Sew the shoulder seam, and press seam apart.
3. Press collar in half lengthwise right side out. Sew collar into front/back neckline.
4. Place fronts right sides together and level edges. Sew zipper to front band edge.
5. Sew shoulder seams of front and back neck facings. Press seam apart Pin front facing to front right sides together and sew along front edge and neckline. Sew from right side. Turn front bands right side out, straighten and press.
6. Sew side seam, press apart.
7. Press waistband in half lengthwise right side out. Sew waistband to jacket.
8. Sew elbow and front sleeve seam, serge and press. Sew sleeves into armholes matching notches, serge and press. Sew cuff into ring. Press cuff in half right side out. Sew cuffs to lower edge of sleeves.
9. Sew seams on lining leaving an opening in seam of right sleeve. Sew lining to inner edges of front facings, back neck facing, inner edge of waistband and to lower edge of sleeves. Turn jacket right side out through the opening in sleeve. Sew opening closed. Make a fastening stitch into waistband connecting seam.

Congratulations, your jacket is ready! :)