

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2210 Dress with zipper

Recommendations on fabric:
natural/mixed fabric suitable for dresses.

You will also need:
fusible interfacing; separating zipper.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Sleeve – cut 2
6. Center front facing - cut 2

7. Back neck facing - cut 1
8. Belt – cut 2

Fusible interfacing:

1. Center front facing - cut 2
2. Back neck facing - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Fold belt in half lengthwise right sides together and sew along long side. Turn belt right side out, straighten, press. Sew decorative stitch at 0.5 – 0.7 cm along the longer edges.
3. Sew side seams, press seams towards back and serge. Pin belt onto the piece and baste together along princess seams.
4. Sew center back seam, press towards left and serge. Sew side backs to center back, press towards center and serge.
5. Pin fronts together, right sides together and adjust edges, measuring the lengths of center front edges. Sew zipper to the center front edge.
6. Sew side fronts to front, press towards center and serge.
7. Sew shoulder seams, press seams towards back and serge.
8. Sew shoulder edges of center front facings and back neckline facing, press seam apart. Serge outer edge. Pin center front facings onto shell right sides together and sew center front edge, neckline edge and lower corner of button stand. Clip into curves, trim away corners, turn pieces right side out.
9. Sew sleeve edges, press seams towards back and serge. Sew sleeves into armholes matching notches, serge, and press.
10. Serge seam allowance along hem of garment and hem of sleeve, press onto wrong side and topstitch.

Congratulations, your dress is ready! :)