

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2335 Loose dress with cowl neck

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: dress zipper.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Upper back - cut 2
2. Upper front - cut 1 on fold
3. Lower back – cut 2
4. Lower front – cut 2
5. Collar — cut 2
6. Sleeve – cut 2
7. Front facing - cut 1 on fold
8. Back facing - cut 2



INSTRUCTIONS:

1. Sew side and shoulder seams of upper parts. Serge seams and press towards back.
2. Sew side edges of back facings and front facings. Press seam apart.
3. Sew side seams of lower parts. Serge seams and press towards back. Sew a gathering stitch along the upper edges of lower backs and lower fronts and gather fullness. Pin facings onto the lower parts of the dress, right side down, and sew along the upper edge. Serge.
4. Pin facing to upper part of the dress, right sides together, and sew lower and upper parts of dress. Clip into curves, trim away corners. Straighten the facing and press lower edge. Sew a stitch line along the upper edge of the facing, from the right side, to fix the edge.
5. Serge separately center back edges. Sew center back seam from neckline up to notch zippers and from notch for zipper to bottom. Press seam apart. Sew in zipper.
6. Sew collar seam. Press seam apart. Sew outer edge of collar into neckline, press seam allowances towards collar. Collar seam is next to left shoulder seam. Fold the seam allowance of the inner side onto the wrong side and press and stitch in the ditch into the seam of the outer side, matching notches.
7. Sew sleeve seams, press towards back and serge. Sew sleeves into armholes, serge, and press.
8. Fold under hem of dress and hem of sleeve two times at 1 cm and topstitch.

Congratulations, your dress is ready! :)