

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2416 Dress with wrap imitation

Recommendations on fabric: natural/mixed knit fabric of small stretchiness in contrasting or similar color.

You will also need: knit fusible interfacing.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm; seam allowance for hem of garment and hem of sleeve – 2.0 cm.

### Main fabric:

1. Back - cut 1 on fold
2. Front right - cut 1
3. Back neck facing - cut 1
4. Front neck facing - cut 1
5. Belt right – cut 1

### Main fabric 1:

1. Front left - cut 1
2. Sleeve - cut 2



### 3. Belt left – cut 1

#### Fusible interfacing:

1. Back neck facing - cut 1
2. Front neck facing – cut

#### INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on front, press bulk towards top.
3. Fold belts in half lengthwise right sides together and sew along long side and one short side. Belt turn right side out, straighten and press.
4. Serge the vertical edges on left and right fronts separately. Sew right front to left front from top to the slit mark, inserting left belt, serge the seam allowances on the slanted area and press towards center. Press apart seam allowances on the vertical area. Topstitch sides of the slit at 0.1 cm from fold.
5. Sew shoulder and side seams, inserting the right belt into the right seam, press seams towards back and serge.
6. Sew shoulder seams of neck facings, press seam apart. Serge outer edge. Pin facing to garment right sides together and sew the neckline. Fold facing onto wrong side, straighten, press. Slipstitch facing to shell along shoulder seams.
7. Sew sleeve seam, press seams towards back and serge. Sew sleeves into armholes, matching notches, serge, and press.
8. Seam allowance for hem of garment and hem of sleeve serge, press onto wrong side and topstitch.

Congratulations, your dress is ready! :)