

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2492 Long silk robe

Recommendations on fabric: thick natural/mixed silk fabrics.

You will also need: fusible interfacing.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance of upper edge of pocket – 4 cm. Seam allowance for hem of garment and hem of sleeve – 3.0 cm.

### Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Pocket – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Apply fusible interfacing to the upper edge of pocket, serge, press onto wrong side and topstitch. Serge the side and lower edges of the pocket, press onto wrong side. Pocket pin onto front and topstitch.
3. Sew shoulder edges of back and front, clipping into seam allowances near corners, press towards back and serge. Sew collar seam, press the seam apart. Sew collar into neckline, press seam allowances towards the collar.
4. Sew shoulder seams of central front facings and facings, clipping into seam allowances near corners, press the seam apart. Sew collar seam, press the seam apart. Sew collar into neckline, press seam allowances towards the collar. Serge the outer edge.
5. Pin center front facings to front right sides together and sew the outer edge of collar, center front facing and lower edge. Clip into curves, trim away corners. Turn the center front facings onto wrong side, straighten, press. Slip stitch together seam allowances along collar seams.
6. Sew sleeves into armholes, matching notches, serge, and press. Sew side seams sewing the sleeve edges at the same time, press towards the back and serge.
7. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

Congratulations, your robe is ready! :)