

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2503 Asymmetric gathered dress

Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.
You will also need: knit fusible interfacing, dress zipper.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm; seam allowance for hem – 2.0 cm; seam allowance for hem of sleeve – 2.0 cm.

Main fabric:

1. Back - cut 2
2. Upper front - cut 1
3. Lower front - cut 1
4. Sleeve – cut 2
5. Stand collar – cut 1

Fusible interfacing:

1. Stand collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew a gathering stitch along the upper edge of lower front from side edge up to notch. Gather fullness. Sew side front to front. Serge and press towards upper front.
3. Sew shoulder and side seams, press seams towards back and serge.
4. Sew outer stand collar into neckline of dress. Press at stand collar. Fold inside the seam allowance of the inner stand collar and stitch-in-the-ditch along seam of outer side.
5. Serge separately center back edges. Sew center back seam from notch for zipper to bottom, press seam apart, pressing the slit for zipper at the same time. Sew in zipper from the upper edge of stand collar down to notch.
6. Sew sleeve seam, press towards back and serge. Sew sleeves into armholes, serge, and press.
7. Serge hem of garment and lower edge of sleeve, press onto wrong side and topstitch.

Congratulations, your dress is ready! :)