

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4038 Dressing gown with shawl collar

Recommendations on fabric: natural or mixed silk fabric.

You will also need: fusible interfacing.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: hems – 3.0 cm, upper edge of pocket - 4.0 cm, other seams – 1.0 cm.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Front facing - cut 2
4. Sleeve - cut 2
5. Back neck facing - cut 1
6. Belt - cut 1

Fusible interfacing:

1. Front facing - cut 2
2. Back neck facing - cut 1

INSTRUCTIONS:

1. Sew center back seam. Serge and press seam towards left side seam.
2. Sew darts on fronts, press bulk towards center.
3. Turn upper edge of pocket under at 1 cm, then again at 3 cm and topstitch. Serge side and lower pocket edges, press under, place on fronts, and topstitch.
4. Sew shoulder seams. Clip in corners. Serge and press towards back. Sew collar seam and press open. Sew collar into neckline. Press seam towards collar.
5. Sew shoulder seams of facings, clip seam in corners. Press seam open. Sew collar into neckline. Press seam towards collar. Serge outer edge.
6. Place front facing on front right sides together and sew along collar fall, front band and lower edge. Fasten together collar connecting seams.
7. Sew sleeves into open armholes matching notches. Serge and press seams. Sew side and sleeve seams with one continuous stitch. Serge and press seams towards back.
8. Serge hem of dress and lower edge of sleeve. Turn under at 1 cm, then again at 2 cm, and topstitch.
9. Fold belt in half lengthwise right sides together and sew long and one short sides. Turn belt right side out. Turn open edges under and topstitch at 0.7 cm from edge along belt perimeter.

Congratulations, your dressing gown is ready! :)