

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

44750 Coat with decoration in sleeves

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; hook and eye, 5 flat buttons for hidden placket, decoration for sleeves.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm; seam allowance for hem of garment and hem of sleeve – 3 cm.

Main fabric:

1. Back yoke – cut 1
2. Back - cut 2
3. Front yoke – cut 2
4. Front - cut 2
5. Center front facing - cut 2
6. Collar - cut 2
7. Back neck facing – cut 1

8. Upper sleeve – cut 2
9. Lower sleeve – cut 2

Lining:

1. Back lining - cut 2
2. Front lining - cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Lining of hidden button panel – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Center front facing- cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew center back seam, press seam apart and serge up to waist. Sew back yoke to yoke, press towards top.
3. Sew front yoke to front, press towards top.
4. Mark closure slit with three lines, on the right side of right button stand (center front facing). The first line should be parallel to vertical edge of closure and runs at 1.5 cm from the edge when ready, the second and third line mark the length of closure. Pin lining (should be with fusible interfacing applied!) onto the center front facing, right sides together, matching the edge of lining with the marked line. Stitch at 0.5 cm from the marked line along the closure slit up to the lines that mark the closure length. Pin the second closure lining, matching its edge with the stitched line, and stitch at 0.5 cm. Check if the stitches are parallel on the wrong side. Cut the slit. Clip into corners at 1.5 cm from the closure ends. Turn the linings onto wrong side through the resulting opening, making a slit frame, which equals the distance between stitch lines. Sew a fixing stitch in the ditch of the lining seam. Press the second lining towards inner edge of center front facing and sew a fixing stitch at 0.1 cm from the lining seam. Mark and make buttonholes. They are made on center front facing and interfaced lining. Straighten the ends of closure and fix them from the wrong side, with double stitch at the base of corners. Sew edges of lining. Make short fastening stitches between each pair of buttonholes, the length of the fixing stitch equals the width of the frame. Press center front facing. 5. Sew side and shoulder seams. Press seam apart.

6. Sew shoulder edges of center front facings and back neckline facing. Press seam apart.
7. Pin upper collar to lower collar and sew corners and fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Turn the collar right side out, straighten and press.
8. Place center front facing onto front right sides together, pin together and sew along the center front edge. Turn center front facings right side out, straighten seams.
9. Sew lower collar into neckline of coat, and upper collar into the neckline formed by back neckline facing and center front facings. Press seam allowances of collar apart and baste together close to the seam.
10. Sew elbow and front seam on sleeve, press seams apart. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap.
11. Sew seams on lining and sew in sleeves. Serge seam allowances from bottom to waist. Fold inside seam allowance of lower edge of lining two times at 1.5 cm and topstitch.
12. Serge, press and finish with hidden stitches seam allowance for hem of garment. Sew lining to inner edges of buttonstands and to back neckline facing. Start and stop stitching at half width of hem fold on the main garment. Clip into seam allowance on inner edge of buttonstand close to seam of lining. Fold inside seam allowance of buttonstand along the area between bottom edge and clipped seam allowance and finish with hidden stitches. Serge seam of lining and press towards lining.
13. Sew lining to hem of sleeve. Press seam towards lining. Sew decoration to sleeve.
14. Sew hook to inner side of right front, sew eye to left front.
Congratulations, your coat is ready! :)