

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 4852 Zippered coat with belt

Recommendations on fabric: soft natural/mixed suiting fabrics.

You will also need: fusible interfacing; separating zipper; 2 grommets  $\varnothing = 2.5 - 3.0$  cm.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

### Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Off-set welt – cut 2
7. Underlay piece – cut 2
8. Casing for drawstring – cut 1
9. Belt – cut 1



Lining:

1. Large pocket bag — cut 2
2. Small pocket bag — cut 2

Fusible interfacing:

1. Center front facing — cut 2
2. Back neck facing — cut 1
3. Off-set welt — cut 2

Also apply fusible interfacing to armholes on back and front, pocket entrance, hem of garment and hem of sleeve.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on front, press bulk towards center, topstitch at 0.5 cm from seam.
3. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew and serge edges of pocket bags.
4. Pin fronts right sides together and adjust edges, measure the length of center front edges. Sew zipper to the center front edge.
5. Sew shoulder seams, press seams towards back and serge.
6. Sew sleeves into armholes, serge, and press.
7. Sew side seams sewing the sleeve edges at the same time, press seams towards back and serge.
8. Sew shoulder seams of button stands and facings, press seam apart. Serge outer edge.
9. Serge and press seam allowance along hem onto wrong side. Place center front facing onto front right sides together. Pin together center front facing and top of garment and sew

along the center front edge and along neckline. Sew lower edge of button stand to front exactly according to the marked line of hem. Turn center front facings right side out onto right side, straighten seams. Sew a decorative stitch along center front and neckline at 0.5 cm.

10. Serge lower edge of sleeve, press onto wrong side and topstitch. Topstitch hem.

11. Press seam allowances of casings onto wrong side, pin it onto Shell according to markings from the wrong side and topstitch along two longer edges at 0.1 cm from the fold. Install grommets according to markings.

12. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Seam Allowances trim away corners, turn belt right side out. Sew the opening closed. Thread belt into casing and grommets.

Congratulations, your coat is ready! :)