

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

6015 Double-breasted overcoat for man

Recommendations on fabric: wool/semiwool fabrics suitable for coats

You will also need: lining; fusing of 210 cm length and 140 cm width, warmer of 80 cm length and 8 cm width, 7 buttons of 27 mm diameter, 6 buttons of 22 mm diameter, shoulder pads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Main fabric:

Main fabric:

1. Back part – 2 pieces
2. Front part – 2 pieces
3. Upper sleeve – 2 pieces
4. Lower sleeve – 2 pieces
5. Outer collar – 1 folded piece
6. Stand-up collar – 1 piece

7. Inner collar – 1 folded piece
8. Off-set welt – 1 piece
9. Half belt – 4 pieces
10. Front band – 2 pieces
11. Flap – 2 pieces
12. Sacking – 2 pieces
13. Facing (rectangle of 17.5x2 cm) – 4 pieces
14. Small sacking (rectangle of 19.5x23 cm) – 1 piece

Lining:

1. Back part+2 cm along middle line (for free-fit pleat)
2. Front part (without front bands)
3. Both sleeves (without slit allowances)
4. Flap, sacking, small sackings – without changes

Lining hems are 2 cm shorter than fabric one.

Fusing: marked segment of lapel, outer/inner collars, flap, stand-ups, hem/sleeve hems, small pocket welt's half width.

INSTRUCTIONS:

NB: when stitching details together, press allowances apart as open.

1. Apply the fusing to wrong side of marked segment of lapel, outer/inner collars, flap, stand-ups, hem/sleeve hems, small pocket welt's half width.
2. Stitch front darts, cut along bendings and press apart as open.
3. Left front part: Bend off-set welt along the center wrong side out, overstitch short edges, turn it right side out and press. Pin downfolded off-set welt on garment's right side according to marks.

Lay lining sacking on off-set welt; pin upfolded fabric sacking on and topstitch along both sides of marking at 5 mm distance. Cut the fabric between stitches chevronwise to stitches' ends; turn sackings into wrong side. Topstitch welt's free edge on the sacking with zig zags. Fold both sackings, adjust them and stitch together along the contour. On right side: stitch welt's ends on the garment.

4. Lay fabric flap on lining one right sides together, stitch along outer edges. Turn the detail right side out, press it and make decorative bastings along edges.

5. Cut slit “frame” pockets with two facings into front parts: Press facings along the center wrong side out. Pin controversially folded facings on garment’s right side according to marks. Lay lining sacking on lower facings. Lay fabric sacking on upper facing inserting flap folded upward between upper facing and fabric sacking and topstitch along both sides of marking at 5 mm distance. Cut the fabric between stitches chevronwise to stitches’ ends; turn sackings into wrong side and make 1-cm facings. Fold the sacking double and topstitch its upper edge on upper facing’s allowance. Stitch sacking’s side edges together. On wrong side: topstitch facing’s ends on fabric triangles.
6. Stitch back pleat and press it toward back middle.
7. Stitch middle back seam up to vent mark.
8. Fold left back part vent’s allowance into right side and stitch along hem line. Then turn right side out and press.
9. Fold right back part’s hem into right side and stitch along vent allowance’s edge, then turn right side out and press.
10. Fold the vent leftward and fix vent’s top with diagonal stitch.
11. Lay half belts right sides together, stitch long and rounded edges together. Turn details right side out, press them and make decorative bastings along edges.
12. Turn the half belt toward middle seam and pin it on back part.
13. Stitch side seams stitching half belts.
14. Press marked segment at shoulder edges, then stitch shoulder seams.
15. Stitch stand-ups to outer/inner collar coinciding marks.
16. Stitch inner collar into fabric neckline right sides together coinciding marks on shoulder seams. Stitch outer collar to front bands.
17. Lay front bands joint with outer collar on the garment right sides together and stitch along collar edge and front edgings. Turn all right side out, press and make decorative bastings along edges.
18. Sew outer collar’s open edge to garment neckline.

19. Press sleeve's upper part together and stitch upper sleeve to elbow part down to slit mark.

Press allowances apart and turn the sleeve right side out. Fold slit allowances and hem allowances into right side, stitch the corner diagonally, cut extra fabric at 1 cm from the seam and press allowances apart. Press allowances into wrong side, sew with cross stitches and overlap the slit.

20. Ease sleeve cap slightly (narrow close stitches) between marks and pull the cord till sleeve cap coincides to armhole. Moist the fabric and iron pleats. Stitch sleeve seam and press allowances apart. Pin sleeves to the garment coinciding marks. Stitch sleeves to garment at sleeve side.

21. Cut the warmer into equal parts and sew it to sleeve caps' wrong sides.

22. Press the hem into wrong side and sew with blind stitches.

23. Sew shoulder pads.

24. Make free-fit pleat and fix it under neckline and few cm above garment's hem. Stitch lining details in the same way as fabric's, leave a segment of 20 cm length into an elbow seam. Lay the lining into fabric garment right sides together, coinciding middle back line and shoulder seams. Overstitch the garment with lining along front bands and neckline. Make a lapping pleat into hem and stitch the lining to hem edge, side vent facing and along back vent facing's edge (before you do it, slash horizontally lining allowances at back vent's hem). Turn the garment right side out through sleeve segment, then stitch segment's edges together.

25. Make buttonholes into half belt, lapels, left front part and top buttonhole into right front part according to marks.

26. Sew buttons.

27. Make buttonholes into sleeves (do not cut the fabric) and fix sleeve slits with buttons.

Congratulations, your overcoat is ready! :)