

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

6016 Double breasted overcoat with patch pockets for man

Recommendations on fabric: wool/semi wool fabrics suitable for coats

You will also need, lining, fusing of 210 cm length and 140 cm width, warmer of 80 cm length and 8 cm width, 9 buttons of 25 mm diameter, shoulder pads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Main fabric:

1. Back part – 2 pieces
2. Front part – 2 pieces
3. Upper sleeve – 2 pieces
4. Lower sleeve – 2 pieces
5. Sleeve lapel – 2 pieces
6. Outer collar – 1 piece
7. Outer stand-up collar – 1 piece
8. Inner collar – 2 pieces
9. Flap – 2 pieces

10. Half belt – 2 pieces
11. Front band – 2 pieces
12. Pocket – 2 pieces

Lining:

1. Back part+2 cm along middle line (for free-fit pleat)
2. Pocket is 4 cm shorter along upper edge
3. Both sleeves, sleeve lapels, half belt and flap – without changes

Lining hems are 2 cm shorter than fabric one.

Fusing: front bands, outer/inner collars, stand-up collar, flap, half belt, pocket allowance, hem allowance and marked segment of front part.

INSTRUCTIONS:

1. Apply the fusing to wrong side of front bands, outer/inner collars, stand-up collar, flap, half belt, pocket allowance, hem allowance and marked segment of front part.
2. Stitch the lining to pocket upper edge, turn right side out, adjust edges and make 1.5 cm stitch along upper edge.
3. Press pocket edges into wrong side and sew them on front parts with blind stitches. Make 1.5 cm stitch.
4. Overstitch the flap with lining, turn right side out and make 1.5 cm stitch.
5. Stitch upfolded flap to front part, fold it down and make 1.5 cm stitch.
6. On back part's wrong side: stitch pleats and press them towards back middle.
7. Stitch back part along middle line up to the vent. Press allowances leftward and make 1.5 cm stitch on right side.
8. Fold left back part vent's allowance into right side and stitch along hem line. Then turn right side out and make 1.5-cm stitch.
9. Fold right back part's hem into right side and stitch along vent allowance's edge, then turn right side out.
10. Make the vent and fix vent's top with diagonal stitch.

11. Overstitch half belts with the lining, turn details right side out and make 1.5 cm stitch.
12. Lay half belts on back part's right side according to marks and tack along edges.
13. Stitch side/shoulder seams.
14. Stitch the stand-up to outer collar, press allowances apart and make stitches along both side of the seam.
15. Stitch inner collar along middle line and press allowances apart.
16. Stitch inner collar into fabric neckline, stitch outer collar to front bands.
17. Lay front bands joint with outer collar on the garment right sides together, adjust edges and overstitch front edgings and the collar. Turn right side out and stitch collars along lower edge.
18. Make 1.5 cm stitch along collar edge/front edgings.
19. Press marked segment of sleeve and stitch upper sleeve to lower one.
20. Stitch each sleeve lapel into ring up to the slit.
21. Overstitch the lapel with the lining, turn the detail right side out and make 1.5 cm stitch.
22. Stitch lining lapel to sleeve hem's right side. Stitch lapel's lower edge to the sleeve along the previous seam.
23. Fold the lapel ready and fix it on the sleeve under slit and on sleeve seam.
24. Ease sleeve cap slightly (narrow close stitches) between marks and pull the cord till sleeve cap coincides to armhole. Moist the fabric and iron pleats. Stitch sleeve seam and press allowances apart. Pin sleeves to the garment coinciding marks. Stitch sleeves to garment at sleeve side.
25. Cut the warmer into equal parts and sew it to sleeve caps' wrong sides.
26. Press the hem into wrong side and sew with blind stitches.

27. Sew shoulder pads.

28. Make free-fit pleat and fix it under neckline and few cm above garment's hem. Stitch lining details in the same way as fabric's, leave a segment of 20 cm length into an elbow seam. Lay the lining into fabric garment right sides together, coinciding middle back line and shoulder seams. Overstitch the garment with lining along front bands and neckline. Make a lapping pleat into hem and stitch the lining to hem edge, side vent facing and along back vent facing's edge (before you do it, slash horizontally lining allowances at back vent's hem). Turn the garment right side out through sleeve segment, then stitch segment's edges together.

29. Make buttonholes into half belt, lapels, left front part according to marks.

30. Sew buttons.

Congratulations, your overcoat is ready! :)