

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 7085 Cargo shorts for boy

Recommendations on fabric: natural/mixed fabric

You will also need: fusible interfacing, 1 zipper, 1 button, Velcro, decorative braid, 2 fixers.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowance: 1 cm for all seams, 3 cm for the hem.

### Main fabric:

1. Waistband – 1 piece
2. Yoke – 2 pieces
3. Back part – 2 pieces
4. Upper front part – 2 pieces
5. Lower front part – 2 pieces
6. Upper pocket – 2 pieces
7. Belt loops – 1 piece
8. Back pocket flap – 4 pieces
9. Small patch pocket – 2 pieces

10. Small pocket flap – 4 pieces
11. Button catch – 1 piece

Interfacing:

1. Waistband – 1 piece
2. Button catch – 1 piece
3. Back pocket flap – 2 pieces
4. Small pocket flap – 2 pieces
5. Pocket entrance allowance

INSTRUCTIONS:

1. Apply the fusing to wrong side of waistband, button catch, flap details, pocket entrance allowance.
2. Lay flap details right sides together and overstitch them. Cut allowances in flap corners and turn them right side out. Make decorative stitch along flap outer contour at 0.5 cm from edge and neaten flap upper edge. Topstitch fiber Velcro part on flaps according to marks.
3. Press small patch pocket's upper edge into wrong side, fold it under and topstitch. Press pocket lower/side edges into wrong side according to pattern. Press hooked Velcro part accordingly to flap. Topstitch the pocket on upper pocket according to marks. Stitch small pocket's flap on upper pocket. Press the flap downwards and topstitch near joining seam.
4. Neaten upper patch pocket's edges: side long edge, pocket entrance edge and lower edge. Press neatened allowances according to pattern. Topstitch pocket entrance allowance at 0.5 cm from edge.
5. Mark front pocket on front part and topstitch pocket side/lower edges at 0.2 cm from pocket outer edge, leaving pocket entrance unstitches.
6. Stitch to yoke to back part inserting the flap between them. Neaten the joining seam and press it towards the yoke. Make decorative stitch along joining seam at 0.5 cm from the seam. Topstitch hooked segments of Velcro on back part according to flap.
7. Stitch upper front part and lower front part together. Press the seam upwards and topstitch along the seam. Make pleats into lower front part.
8. Neaten front/middle edges of garment parts and garment lower edges (hems). Stitch inside leg seams and neaten them, press backwards. Stitch side seams to the mark, press

them apart and neaten. Stitch front edges together; stitch middle edge up to closure notch. Make another stitch along crotch seam near the seam joining front seam and middle seam.

9. Press closure one-piece facings into wrong side. Stitch the zipper edges closure left edge. Stitch zipper free braid to right one-piece facing. Fold buttons catch along the center and overstitch lower short edge. Topstitch closure one-piece facing on zipper on left button catch. Topstitch slit right edge catching the facing.

10. Fold belt loop along the center wrong side out, adjust edges and overstitch at 0.5-0.7 cm from edges. Then turn it right side out, placing the seam along fold line or making an edging of 0.1-0.2 with into wrong side, and press.

11. Press the waistband along the center right side out and neaten lower inner edge of it. Cut belt loops according to size and topstitch them on garment upper edge.

12. Stitch the waistband to garment upper edge. Overstitch waistband ends, cut corner allowances, and turn the waistband right side out. Topstitch waistband lower neaten edge on joining seam and press ready waistband.

13. Press hem allowance into wrong side and topstitch it. Pull decorative stitch into this coulisse and fix it with fixers.

14. Make buttonhole into waistband right end, sew buttons on left one.

Congratulations, your shorts are ready! :)