

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 7115 Jacket with patch pockets and hood

Recommendations on fabric: soft wool  
You will also need: fusible interfacing, 1 separating zip, decorative cord, 2 tabs.

### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowance: 1 cm for all seams, 3 cm for hems and hood's outer edge.

### Main fabric:

1. Front part – 2 pieces
2. Back part – 2 pieces
3. Pocket – 2 pieces
4. Flap – 4 pieces
5. Front band – 2 pieces
6. Back neckline facing – 1 piece
7. Sleeve – 2 pieces
8. Sleeve facing – 2 pieces
9. Hood side – 2 pieces
10. Hood center – 1 piece

Fusible interfacing:

1. Front band – 2 pieces
2. Back neckline facing – 1 piece
3. Flap – 2 pieces

#### INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Apply fusible interfacing to the wrong side of the front bands, back neckline facing, and flap details.
2. Place the flaps right sides together and stitch along three edges. Trim the seam allowances, turn the flap right side out, and press. Topstitch around the perimeter of the flap.
3. Stitch the hood sides to the hood center and neaten the seams. Create eyelets in the hood for the cord. Fold the outer hood allowance to the wrong side, fold it under, and topstitch on the hood.
4. Neaten the outer contour of the pocket and press it according to the pattern. Fold the upper edge to the wrong side and topstitch. Topstitch the pocket onto the front part, marking the position of the flap. Attach the flap according to the marks, press it downward, and topstitch close to the joining seam.
5. Place the front parts right sides together, align the edges, and measure the length of the front edgings. Attach the zipper to the edgings. Press the closure edges under.
6. Stitch the center back seam. Press the seam allowance to the left and topstitch the left back piece along the seam.
7. Sew the side and shoulder seams.
8. Attach the back neckline facing to the front bands. Neaten the outer edges of the front bands and facing. Place the front band on the front part with right sides together, and stitch along the front edge and neckline, inserting the hood in between. (Stitch from the side of the front part.) Sew the lower corner of the front edge. Turn the front edgings right side out and press.

9. Press the upper edge of the sleeve facing. Attach the facing to the sleeve. Stitch the sleeve seams and neaten them. Press the sleeve seams. Topstitch the pressed edge of the facing onto the sleeve. Attach the sleeves to the armholes, matching notches.

10. Make a decorative topstitch 0.5 cm from the zipper. Insert the cord through the hood eyelets and attach tabs to the ends of the cord.

Congratulations, your jacket is ready! :)