

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4692 Trousers in knitted fabric

Recommendations on fabric: natural or mixed, low stretch knit fabric.

You will also need: stretchy fusible interfacing, elastic, cord for waistband, 2 eyelets.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: hem – 2.0 cm; all other seams - 1.0 cm.

Main fabric:

1. Back waistband - cut 1
2. Front waistband – cut 1
3. Front – cut 2
4. Side – cut 2
5. Pocket sacking – cut 2
6. Back – cut 2
7. Off-set welt - cut 2
8. Underlay piece - cut 2
9. Belt loop - cut 1

Fusible interfacing:

1. Off-set welt - cut 2

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Pin sacking to front and sew pocket opening on a lockstitch machine. Clip seam on curves, turn sacking to inside and topstitch seam on sacking with 0.1 cm stitch. Press.
2. Pin front on side piece according to marking. Sew sacking to side piece, serge seam. Make and fasten pleats according to marking (folds are directed towards side edges). Pin sacking to front on upper and side edges.
3. Mark back pockets location. Apply fusible interfacing to pocket opening. Fold off-set welt in half lengthwise wrong sides together. Sew welt to back on lower line of pocket marking. Sew underlay piece to back on upper line of pocket marking. End short lines of marking. Check stitches from inside - they must be parallel. Cut pocket opening. Make cuts to corners at 1 - 1.5 cm from ends. Turn welt and underlay piece to inside through the pocket opening. Adjust ends of welt so that fold and underlay piece connecting seam were on one line. Fasten ends of pockets from inside with double back stitch. Topstitch off-set welt onto underlay piece on connecting seam.
4. Sew center back seam, serge and press seam towards left side. Sew center front seam, serge and press seam towards left side.
5. Sew side seams. Serge and press seams towards back. Sew inner leg seams. Serge and press towards back.
6. Install two eyelets for cord on front waistband. Sew waistbands together into ring. Sew elastic into ring. Fold and press waistband in half lengthwise wrong sides together. Mark lines for elastic on back waistband and topstitch. Set elastic into waistband, fasten inside seams. Thread the cord and fasten inside seams. Sew waistband to trousers, serge seam.
7. Serge bottom edge of trousers, turn under, press, and topstitch.
8. Serge one long edge of belt loop. Fold loop in three layers and topstitch on long sides. Cut loop into 6 pieces. Topstitch belt loops on waistband according to technical drawing.

Congratulations, your trousers are ready! :)